

TURBOCHARGER PRE-INSTALLATION GUIDE

4 EASY STEPS TO GET THE JOB DONE RIGHT!





CHANGE ENGINE OIL

1

2

REPLACE OIL FILTER




REPLACE AIR FILTER

3

4

**PRE-LUBE THE
TURBOCHARGER**

A turbocharger running for **5 SECONDS** with no oil is equivalent to an engine running **5 MINUTES** with no oil.



CALL 855-246-7529

FOR EXPERT ADVICE AND INSTALLATION ASSISTANCE